

## DIFFUSION TRANSFER SYSTEM

23 APRIL 1968 *rym*

NUMBERS DENOTE STEPS IN THE PROCESSING OPERATION. ARROWS DENOTE MATERIAL MOVEMENT.

- 1.- TAKE O.N. INTO SHELTER TO BREAKDOWN AREA.
- 2.- BREAK-DOWN INTO 500 FT. ROLLS.
- 3.- PLACE IN PASSBOX OR ONTO TRISPIN.
- 4.- LOAD BIMAT FILM ONTO TRISPIN.
- 5.- LAMINATE O.N. & BIMAT.
- 6.- PLACE LAMINATE IN PASSBOX FOR PROCESSING.
- 7.- LOAD O.N.-BIMAT LAMINATE ONTO PENTASPIN.
- 8.- LOAD DESIMAT TAPE ONTO PENTASPIN.
- 9.- LOAD COVERSHEET ONTO PENTASPIN.
- 10.- DELAMINATE O.N. FROM BIMAT POSITIVE - AND
- 11.- LAMINATE O.N. WITH DESIMAT TAPE - AND
- 12.- LAMINATE BIMAT POSITIVE WITH COVERSHEET.
- 13.- PLACE FINISHED BIMAT POSITIVE ON STORAGE SHELF.
- 14.- PLACE O.N.-DESIMAT TAPE LAMINATE IN PASSBOX.
- 15.- LOAD O.N.-DESIMAT TAPE LAMINATE ONTO TRISPIN.
- 16.- DELAMINATE DESIMAT TAPE FROM O.N.
- 17.- PLACE USED DESIMATE TAPE ON STORAGE SHELF.
- 18.- PLACE FINISHED O.N. IN PASSBOX.
- 19.- LOAD O.N. ONTO DRIAGARA.
- 20.- LOAD DRIMAT FILM ONTO DRIAGARA.
- 21.- LOAD DUPE STOCK ONTO DRIAGARA.
- 22.- PRINT DUPE - AND
- 23.- LAMINATE PRINTED DUPE AND DRIMAT FILM.
- 24.- PLACE DUPE-DRIMAT LAMINATE ON STORAGE SHELF.
- 25.- PLACE O.N. IN PASSBOX.